

Tips

## Permit to Work (Critical Tasks)

*All high risk work requires a permit. Make sure you know when permits are required.*



## Toolbox talk

# Permit to Work (Critical Tasks)

**The following items are either notifiable work or require a task analysis or permit to work prior to commencing the task:**

Erection or modification of scaffolding above 5 metres

WorkSafe NZ

Confined spaces

WorkSafe NZ

Prescribed electrical work

WorkSafe NZ

Removal of friable asbestos

WorkSafe NZ

Excavation work

WorkSafe NZ

Approved Code of Practice  
Excavations and Shafts  
for Foundations  
[www.business.govt.nz](http://www.business.govt.nz)

Hot work

Site Specific Safety Plan Self  
Safety Inspection Point 9.1

Demolition

WorkSafe NZ

Powder operated tools

Site Specific Safety Plan Self  
Safety Inspection Point 12.1 – 12.3  
ACOP: Powder Actuated Handheld  
Fastening Tools.

Working at heights

Approved Guidelines for Working  
at Height